



TEST REPORT

Report No. : MAN:HL:1348003886

DATE : 07-May-22



CEPHAS MEDICAL PRIVATE LIMITED

DP 33, 34, 46 & 47, SIDCO INDUSTRIAL ESTATE (URBAN)

Tamil Nadu, VIRUDHUNAGAR-626103

IN

CONTACT PERSON : C.R. SARAVANAN

THE FOLLOWING SAMPLE(S) WAS/WERE SUBMITTED AND IDENTIFIED BY/ON BEHALF OF THE CUSTOMER AS :

PRODUCT DESCRIPTION 18 INCH NITRILE UNLINED GLOVES
COLOUR GREEN
STYLE NO. CNU18
COUNTRY OF DESTINATION INDIA
COUNTRY OF ORIGIN INDIA
SAMPLE RECD ON 30-Apr-2022 **TESTING PERIOD : 30-Apr-22 - 07-May-22**

TESTS	PASS	FAIL	REMARKS
US FDA 21 CFR 177.2600 (RUBBER ARTICLES)-DETERMINATION OF AMOUNT OF EXTRACTIVES	P		

Remarks: P=Pass

F=Fail

per pro SGS India Private Ltd.

SANDIP BHUSHAN (Tech. Manager)

Authorized Signatory

Email your Test Report Related Enquiries at Feedback.HLT@sgs.com

JOE No. : 2248801645

Page 1 of 3

Control No.:1348504941

This document is issued by the Company under its General Conditions of Service printed overleaf or available on request and accessible at http://www.sgs.com/terms_and_conditions.htm and Terms and Conditions for electronic documents www.sgs.com/terms_e-document.htm. Attention is drawn to the limitation of liability, indemnification and jurisdiction issues defined therein. Any holder of this document is advised that information contained hereon reflects the Company's findings at the time of its intervention only and within the limits of Client's instructions, if any. The Company's sole responsibility is to its Client and this document does not exonerate parties to a transaction from exercising all their rights and obligations under the transaction documents. Any unauthorized alteration, forgery or falsification of the content or appearance of this document is unlawful and offenders may be prosecuted to the fullest extent of the law.

Unless otherwise stated the results shown in this test report refer only to the sample(s) tested and such sample(s) are retained for 30 days only. This document cannot be reproduced except in full, without prior approval of the Company.

TEST REPORT

Report No. : MAN:HL:1348003886

DATE : 07-May-22



R E S U L T S

REQ

US FDA 21 CFR 177.2600 (RUBBER ARTICLES)-DETERMINATION OF AMOUNT OF EXTRACTIVES

Method: With reference to US FDA 21 CFR 177.2600

For use in contact with aqueous food:

Extractants	Test Condition	Result (mg/inch ²)	Reporting Limit (mg/inch ²)	Permissible Limit (mg/inch ²)
Distilled Water	Reflux temperature for 7 hours	5.58	0.1	20
	Succeeding 2 hours of extraction	0.63	0.1	1

For use in contact with fatty food:

Extractants	Test Condition	Result (mg/inch ²)	Reporting Limit (mg/inch ²)	Permissible Limit (mg/inch ²)
n-Hexane	Reflux temperature for 7 hours	0.87	0.1	175
	Succeeding 2 hours of extraction	0.60	0.1	4

CONCLUSION **PASS**

Note:

- mg/inch² = milligram per square inch
- ND = Not Detected
- Testing has been subcontracted to SGS Gurugram lab.
- Testing has been performed as per customer request.

***** End of Page*****

TEST REPORT

Report No. : MAN:HL:1348003886

DATE : 07-May-22



R E S U L T S

REQ



***** End of Report *****